


# BRUKSANVISNING INSTRUCTION MANUAL

## TERRASSEVARMER GULV 1500W



220-240V~ 50/60Hz 1500W IP34




Spenning: 220-240V~ 50/60Hz  
Effekt: 1500W  
Tetthetsgrad: IP34  
Inkludert 1,8 meter kabel og IP44 støpsel


Voltage: 220-240V~ 50/60Hz  
Power: 1500W  
IP rating: IP34  
Include 1.8m cable and IP44 plug

### Parts / Deler

1. Bryter / Switch
2. Frontplate / Front plate
3. Reflekterende panel / Reflecting panel
4. Varmeelement / Heating element
5. Beskyttelsesgitter / Protection grid
6. Bakplate / Back plate
7. Aluminiumsdeksel / Aluminum cover
8. Balansevekt / Balance weight
9. Kabel og støpsel / Cable and power supply plug



### MÅL / MEASURES



### SIKKERHET / SAFETY

Kontroller at kontakten er jordet. Må ikke tildekkes, ovnens overflate kan bli svært varm og må plasseres i trygg avstand fra brennbart materiale. Koble fra strømmen ved vedlikehold. Ovnens må brukes under tak, ikke i nærheten av vann eller brennbare væsker/gass. Ved bruk av skjøteledning må den være kortest mulig og være utstrakt når ovnen er på.

Make sure that the outlet is grounded. Do not cover the heater surface, the heater can become very hot and must be placed at a safe distance from flammable material. Disconnect power during maintenance. The heater must be used under ceiling, not near water or flammable liquids/gas. If using an extension cord it must be as short as possible and be extended when the oven is on.