




GEY7355901

Wi-Fi Accesspunkt



WDE002969




5-portars Gbit switch 4 PoE portar

Budget 57W
30W max/port



R9H5SWP57




OU

9-portars Gbit switch 8 PoE portar

Budget 92W
30W max/port



R9H9SWP92



Exxact Wi-Fi Accesspunkt

Installationsguide

Life Is On

Schneider
Electric


A Nätverk: installera och anslut switchen eller PoE-styrenheten i mediaskåpet

Spelrum



Arbetsstation för distansarbete


Väggmonterad Exxact
Wi-Fi Accesspunkt



Till Exxact Wi-Fi
Accesspunkt

Mediaskåp

RJ45 kabel




RJ45


RJ45

ACTPC6UULS05WE

Patchpanel




PoE
Switch




ISP-ingång

Router








Område för elbilsaddning






Nätverkskabel
Mediaskåp
Eicentral

Nätverkskabel
Mediaskåp
Eicentral



B Installera och anslut till Wi-Fi Accesspunkten



C Konfigurera



RESET
Om SYS-LED blinkar, tryck och håll inne knappen i 8 sekunder



RJ45 till PoE switch eller PoE-styrenhet (IEEE 802.3af)

Life Is On



Schneider Electric Industries SAS
35, rue Joseph Monier
92500 Reuil-Malmaison, France
www.schneider-electric.com